


# LOCINOX®

Let's make better fences together

## MAGUNIT-2500: INSTALLATION INSTRUCTION

### ① Package content




SHIM PLATE



TOP COVER



BOTTOM COVER




QUICK-FIX

DIN7983 ST4.8x19


DIN7991 M8x45

N-LINE-B-MAG


MAGUNIT-2500



ANCHOR PLATE



POSITIONING NUTS



SHIM PLATE




TOP COVER



BOTTOM COVER



DIN7092-8



QUICK-FIX


DIN7983 ST4.8x19

DIN7984-M8x50


N-LINE-S-MAG

### ② N-LINE-B-MAG: Swing Gate Configurations


1x MAGUNIT-2500



2x MAGUNIT-2500




3x MAGUNIT-2500




### ② N-LINE-S-MAG: Sliding Gate Configurations


1x MAGUNIT-2500



2x MAGUNIT-2500



3x MAGUNIT-2500




### ③ Fence post preparation for MAGUNIT-2500


**N-LINE-B-MAG**

**N-LINE-S-MAG**



LEFT HAND SWING GATE




RIGHT HAND SWING GATE




SLIDING GATES



LASER CUT




LASER CUT




LASER CUT


④ Adjusting N-LINE-B-MAG Length & Drilling Holes




⑤ Aligning and placing templates




⑥ Placing square nuts




④ Adjusting N-LINE-S-MAG Length & Drilling Holes




⑤ Aligning and placing templates



⑥ Placing square nuts




⑦ Placing anchorplates, shim plates and covers





⑧ Drill holes in gate frame and mount N-LINE-MAG


**LEFT HAND GATE**




**RIGHT HAND GATE**




⑦ Bottom cover installation




⑧ Drill holes in gate frame and mount N-LINE-MAG




⑨ Placing anchorplates, shim plates and covers





⑨ MAGUNIT installation



⑩ MAGUNIT installation



12 AND 24V DC - SITUATION



**LOCINOX**®

Let's make better fences together

**Doc. Nr.:**  
**MANU-000229**

Locinox nv • Mannebeekstraat 21  
B-8790 Waregem • Belgium - Europe  
Tel. +32 (0)56 77 27 66  
E-mail: locinox@locinox.com

Locinox USA LLC • 460-464 Windy Point Drive  
Glendale Heights • IL60139  
Tel. 877-LOCINOX • Fax. 708-579-0978  
E-mail: salesusa@locinox.com



\* M A N U - 0 0 0 2 2 9 \*